

WI-FI LINK INSTRUCTIONS:

1. Download “**WIFI ACTION CAMERA**” app on your Android phone/tablet or on iPhone/iPad (NOTE: if the App cannot be found by searching the store – please scan the appropriate QR code provided for your convenience here below and choose to link to the store)
2. Press **PIC** button for 3 seconds to activate your monocular WI-FI setup. Look through the eyepiece and observe the WI-FI link name and Password. The Wi-Fi link is the first line of the screen and the password is on the second line.
3. Open the App
4. Click on “Connect Camera”
5. Click on “Go Settings”
6. Find the Wi-Fi link (same as first line shown on the unit’s LCD display) and click on it
7. Enter password (second line of the unit’s LCD display) – NOTE: only numbers after “:” are needed to be entered – typical default password is 12345678
8. Close the app and open the App again and click on “Connect Camera”
9. Green check (✓) sign means camera is now connected
10. Follow on screen menu on your mobile phone to utilize the available features of the app.



Android QR code



Apple QR code